

BBR

MOTORSPORTS

1028 4th St. SW, A, Auburn, WA 98001 · Phone: (253) 631-8233 · Fax: (253) 631-4260 · www.bbrmotorsports.com

BBR Aluminum Frame Kit - TT-R 125 Assembly Notes

Step 1: Install the engine into the bare frame, from the right side, head first (up through the frame spars).

Step 2: Install lower rear motor mount bolt. Install swingarm and upper rear motor mount (swingarm bolt goes through this mount). Suspension linkage can be installed at this time.

Step 3: Install header.

Step 4: Install front motor mount bolts and plates.

Step 5: With airbox assembly removed from the subframe, install carburetor and intake manifold onto airboot. Slide carb into place and bolt to cylinder head.

Step 6: Install shock

Step 7: Slide subframe over airbox and bolt airbox to subframe.

Continue assembly as per standard CR80/85.

- Notes:
- ° Rear master cylinder reservoir attaches to upper rear motor mount.
 - ° When installing rear tank strap, cut the stock safety cable to allow it to stretch the necessary amount.
 - ° Right side footpeg mount comes with spring. Left side footpeg mount uses the stock CR80/85 spring.